

Brzdové obložení Bremskerl

objednací číslo	název	aplikace	obrázek
19010 - 00 brem	WVA19010.0; 21 Q 6520	DAF	
19032 - 00 brem	WVA 19032.0; 17,5 Q 6500	BPW	
19032 - 01 brem	WVA 19032.1; 19 Q 6500	BPW	
19063 - 00 brem	WVA 19063.0; 21 Q 6520	DAF	
19187 - 00 brem	WVA 19187.0; 18 Q 6520	HEULIEZ KAROSA, LIAZ	
19187 - 01 brem	WVA 19187.0; 18,5 Q 6520	HEULIEZ KAROSA, LIAZ	
19283 - 00 brem	WVA 19283.0; 20,60; Q 6500	SAF	
19283 - 01 brem	WVA 19283.1; 21,6 Q 6500	SAF	
19486 - 00 brem	WVA 19486.0 = 19494.0; 17; Q 6520		
19487 - 00 brem	WVA 19487.0 = 19495.0; 17 Q 6520		
19487 - 01 brem	WVA 19487.1 = 19495.1; 18,30 Q 6520		
19488 - 00 brem	WVA 19488.0 = 19496.0; 17 Q 6520	MB, MAN	
19488 - 01 brem	WVA 19488.1 = 19496.1; 18,30 ; Q 6520	MB, MAN	
19515 - 00 brem	WVA 19515.0; 15,20 Q 6510	KAISER, KASSBOHRER	
19515 - 01 brem	WVA 19515.1; 15,70 Q 6510	KAISER, KASSBOHRER	
19557 - 00 brem	WVA 19557.0; 19,00 Q 6500	SMB	
19557 - 01 brem	WVA 19557.1; 20 Q 6500		
19574 - 00 brem	WVA 19574.0; 17,8 Q 6510	BPW	
19574 - 01 brem	WVA 19574.1; 19,00 Q 6510	BPW	
19902 - 00 brem	WVA 19902.0 (4+4) ; 17 Q 6510	BPW, GORICA	
19902 - 01 brem	WVA 19902.1 (4+4) ; 19 Q 6510	BPW, GORICA	
19932 - 00 brem	WVA 19932.0; 19,1; Q 7099	SCANIA	
19932 - 01 brem	WVA 19932.1; 20,10 Q 7099	SCANIA	
19933 - 00 brem	WVA 19933.0; 19,1 Q 7099	SCANIA	
19935 - 00 brem	WVA 19935.0; 18,00 Q 6520	RENAULT	

Brzdové obložení Bremskerl

objednací číslo	název	aplikace	obrázek
19938 - 00 brem :	WVA 19938.0 (19090.0); 18,2 Q 7099		
19938 - 01 brem	WVA 19938.1 = 19090.1; 19,70 Q 7099		
19939 - 00 brem	WVA 19939.0; 18,20 Q 7099	STEYR, VOLVO	
19939 - 01 brem :	WVA 19939.1 19071; 19,7; Qlty. 7099	STEYR, VOLVO	