








## Kotoučové desky Bremskerl

objednáací číslo	název	aplikace	obrázek
2 - EDB 1047 Brem	Kot. brzda EDB 1047 (WVA 29090) Q 6565	VOLVO, RENAULT, MAHNUM, HEULIEZ, DENNIS	<p>WVA# 29090</p>
2 - EDB 1275 Brem*	Kot. brzda EDB 1275 (WVA 29093, 095) Q 8010	MAN, MERCEDES, KNORR, SOR	<p>WVA# 29093 / 29095 / 29197</p>
2 - EDB 1277 Brem	Kot. brzda EDB 1277 ( WVA 29115, 29148 ) Q 6565	MERCEDES, KNORR, SAE	
2 - EDB 1279 Brem *	Kot. brzda EDB 1279 (WVA 29088) Q 8010	MAN, RENAULT, DAF	<p>WVA# 29088</p>
2 - EDB 1314 Brem *	Kot. brzda EDB 1314 (WVA 29106) Q 8010	IVECO, KAROSA, KASSBOHRER, KNORR, LIAZ, SCANIA	<p>WVA# 29106</p>
2 - EDB 760 Brem *	Kot. brzda EDB 760 (WVA 29030, 083, 084, 113, 114) Q 8010	LUCAS, DENNIS, ERF, HEULIEZ, KAROSA, KASS, MAN	<p>WVA# 29030 / 29210</p>
2 - EDB 773 Brem	Kot. brzda EDB 773 (WVA 29011) Q 6565	IVECO	
2 - EFC 113 Brem *	Kot. brzda EFC 113 (WVA 29126) Q 8010	SAF, DAF, DENNIS, MERCEDES, RENAULT, SMB, SOR	<p>WVA# 29126</p>
2 - EFC 121 Brem *	Kot. brzda EFC 121 (WVA 29125) Q 8010	MERITOR, TRAILERS, VOLVO	<p>WVA# 29125</p>
2 - EFC 124 Brem *	Kot. brzda EFC 124 (WVA 29131) Q 8010	MAN, MERITOR, RENAULT, TRAILERS	<p>WVA# 29131</p>
2 - EFC 131 Brem *	Kot. brzda EFC 131 (WVA 29165, 29215) Q 8010	BPW, KNORR, TRAILERS	<p>WVA# 29165</p>



## Kotoučové desky Bremskerl

objednáací číslo	název	aplikace	obrázek
2 - EFC 132 brem *	Kot. brzda EFC 132 (WVA 29171) Q 8010	BPW, SAF	
2 - EFC 132 SAF brem *	Kot. brzda JCP 1002 SAF (WVA 29158) Q 8010	BPW, KNORR, TRAILERS	
2 - EFC 133 brem *	Kot. brzda EFC 133 (WVA 29167, 29216) Q 8010	BPW, KNORR, MERCEDES, TRAILERS, ZF AXLES	
2 - JCP 005 brem *	Kot. brzda JCP 005 ( WVA 29162 ) Q 8010	Discos Trailers, Gigant Axles, SAF, SMB, Wabco	
2 - JCP 006 brem *	Kot. brzda JCP006 (WVA 29174, 29204, 29219, 29226) Q 8010	MERITOR, RENAULT, VOLVO	
2 - JCP 013 brem*	Kot. brzda JCP 013 K (WVA 29173, 29203, 29272) Q 8010	MERITOR, RENAULT, VOLVO	